



[Navigator & NavigatorPlus Software Downloads](#)

PostBase leveres som standard med Navigator Software for hurtig adgang til Postbase maskinens opsætningsfunktioner fra en local pc. Navigator standard programmet kan opgraderes til NavigatorPlus, hvis man har behov for detaljerede transaktionsrapporter eller export af data fra Postbase. NavigatorPlus kan dog ikke bruges til model 30.

Installer Navigator eller NavigatorPlus

Download og installer alle filer fra links nedenfor. OBS! Download og installer i nøjagtig den rækkefølge, som links vises i herunder. *Administrator rettigheder er nødvendige i step 1 og 2. Step 3 kan udføres af enhver bruger.*

Step 1 Installer Microsoft .NET 4.0

***Microsoft .NET 4.0: Bemærk** NET version 4.0 kræves installeret på pc'en. Andre .NET versioners vil ikke fungere med de efterfølgende programmer.



[Microsoft .NET 4.0*](#) Navigator /NavigatorPlus software.

Step 2 Installer Postbase Driver



[PostBase Driver Setup](#)

Step 3 Installer Navigator software



[Navigator /NavigatorPlus](#)

Navigator & NavigatorPlus

Operating-System Requirements: Windows XP, Vista, or Windows 7 Windows 8 (just Navigator/NavigatorPlus)

SYSTEM REQUIREMENTS (hardware)

- PC with 233MHz processor clock speed (single or dual processor system); Intel Pentium/Celeron family or AMD K6/Athlon/Duron family or compatible processor
Recommended Clock Speed 1GHz (or faster)
- 256 megabytes (MB) of RAM
Recommended RAM 512 MB

2.0 gigabytes (GB) or available hard disk space

Super VGA (1024 x 768) resolution video adapter and monitor

Windows XP-Professional SP2 operation system, Windows Vista , Windows 7, Windows 8

(Supporting 32/64 bit operations systems)

- Keyboard and mouse or compatible pointing device
- Microsoft Internet Explorer version 6.0 (IE6) **or later**
- 2 available USB Ports
- MS .NET Framework 4.0 or higher
- High Speed Internet Connection